Mobile Application Development Laboratory Lab 6

Menu and SharedPreferences

Roll: **106118103** Name: **V. Aananth**

Aim:

To make an android application that implements Menu and SharedPreferences.

Description of App:

We create an android application with the following specifications:

- 1. In an activity, have a Menu with a list of Menu Items such as Help, Control, Settings, Exit. Upon clicking on the Menu Items, do the following.
 - Help Open help page of android using browser
 - Settings Open settings app of the mobile
 - Exit exit the application
 - Control Have options for the following:
 - Switch on/off bluetooth
 - Increase or decrease the brightness value
 - Control the mobile volume
 - Change orientation of the mobile phone
- 2. Have text views and textboxes to get name, email id, mobile number from user and store it in SharedPreferences upon clicking a Button. Have another button, upon clicking which, retrieve the information entered and display it on the screen.

Device Specifications:

Model: Poco F1

Android Version: 9 (API Level 28) Resolution: 2160 x 1080 pixels

Technical Concepts Learnt:

- To create and inflate Menus.
- To create and use SharedPreferences.
- To navigate and pass information between Activities using SharedPreferences.
- To declare and obtain user-permissions.

Source Code:

(i) MainActivity.java

```
package com.example.lab6;
import ...
public class MainActivity extends AppCompatActivity {
    int currentScreenBrightness;
    int currentVolume;
    private ContentResolver cResolver;
    private Window window;
    AudioManager mAudioManager;
    EditText mName, mEmail, mContact;
    Button mSubmit, mView;
    Boolean isStored = Boolean.FALSE;
    SharedPreferences mSharedPreferences;
    @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.activity_main);
        if (!Settings.System.canWrite(getApplicationContext())) {
            Intent intent = new
Intent(Settings.ACTION_MANAGE_WRITE_SETTINGS, Uri.parse("package:" +
getPackageName()));
            Toast.makeText(getApplicationContext(), "Please, allow
system settings for automatic logout ", Toast.LENGTH_LONG).show();
            startActivityForResult(intent, 200);
        }
```

```
cResolver = getContentResolver();
       window = getWindow();
       try
        {
            // To handle the auto
            Settings.System.putInt(cResolver,
                    Settings.System.SCREEN_BRIGHTNESS_MODE,
Settings.System.SCREEN BRIGHTNESS MODE MANUAL);
            //Get the current system brightness
            currentScreenBrightness =
Settings.System.getInt(cResolver, Settings.System.SCREEN_BRIGHTNESS);
        catch (Settings.SettingNotFoundException e)
        {
            //Throw an error case it couldn't be retrieved
            Log.e("Error", "Cannot access system brightness");
            e.printStackTrace();
        }
       mAudioManager = (AudioManager)
getApplicationContext().getSystemService(Context.AUDIO SERVICE);
        currentVolume =
mAudioManager.getStreamVolume(AudioManager.STREAM MUSIC);
       mName = (EditText) findViewById(R.id.name);
       mEmail = (EditText) findViewById(R.id.email);
       mContact = (EditText) findViewById(R.id.phone);
       mSubmit = (Button) findViewById(R.id.submit);
       mView = (Button) findViewById(R.id.view);
       mSharedPreferences =
getSharedPreferences(((Lab6Application)this.getApplication()).getSPKe
y(), Context.MODE PRIVATE);
        String[] keys =
((Lab6Application)this.getApplication()).getSPValueKeys();
        getSPreferences();
```

```
checkEmptyVal();
        mSubmit.setOnClickListener(new View.OnClickListener() {
            @Override
            public void onClick(View view) {
                String name = mName.getText().toString();
                String email = mEmail.getText().toString();
                String contact = mContact.getText().toString();
                if (name.equals("") || email.equals("") ||
contact.equals("")) {
                } else {
                    SharedPreferences.Editor editor =
mSharedPreferences.edit();
                    editor.putString(keys[0], name);
                    editor.putString(keys[1], email);
                    editor.putString(keys[2], contact);
                    editor.commit();
                    isStored = Boolean.TRUE;
                    Toast.makeText(getApplicationContext(), "Saved in
Shared Preferences", Toast.LENGTH_SHORT).show();
            }
        });
        mView.setOnClickListener(new View.OnClickListener() {
            @Override
            public void onClick(View view) {
                if(isStored != Boolean.TRUE) {
                } else {
                    Intent intent = new
Intent(getApplicationContext(), ViewActivity.class);
                    startActivity(intent);
            }
        });
```

```
}
   @Override
   public boolean onCreateOptionsMenu(Menu menu) {
       MenuInflater inflater = getMenuInflater();
        inflater.inflate(R.menu.main menu, menu);
       return true;
    }
   @Override
   public boolean onOptionsItemSelected(MenuItem item) {
        // Handle item selection
        switch (item.getItemId()) {
            case R.id.help:
                String url = "https://developer.android.com/";
                Intent helpIntent = new Intent(Intent.ACTION VIEW);
                helpIntent.setData(Uri.parse(url));
                startActivity(helpIntent);
                return true;
            case R.id.settings:
                Intent settingsIntent = new
Intent(Settings.ACTION_SETTINGS);
                startActivity(settingsIntent);
                return true;
            case R.id.exit:
                finishAndRemoveTask();
                return true;
            case R.id.clear sp:
                clearSharedPreferences();
                getSPreferences();
                Toast.makeText(getApplicationContext(), "Shared
Preferences Cleared", Toast.LENGTH SHORT).show();
                return true;
            case R.id.bluetooth:
                BluetoothAdapter mBluetoothAdapter =
```

```
BluetoothAdapter.getDefaultAdapter();
                if (mBluetoothAdapter.isEnabled()) {
                    mBluetoothAdapter.disable();
                    Toast.makeText(getApplicationContext(),
"Bluetooth Disabled", Toast.LENGTH SHORT).show();
                else {
                    mBluetoothAdapter.enable();
                    Toast.makeText(getApplicationContext(),
"Bluetooth Enabled", Toast.LENGTH SHORT).show();
                return true;
            case R.id.b inc:
                setBrightness(currentScreenBrightness + 64);
                Toast.makeText(getApplicationContext(), "Brightness
Increased", Toast.LENGTH SHORT).show();
                return true;
            case R.id.b dec:
                setBrightness(currentScreenBrightness - 64);
                Toast.makeText(getApplicationContext(), "Brightness
Decreased", Toast.LENGTH_SHORT).show();
                return true;
            case R.id.v inc:
                setVolume(currentVolume + 25);
                Toast.makeText(getApplicationContext(), "Volume
Increased", Toast.LENGTH SHORT).show();
                return true;
            case R.id.v dec:
                setVolume(currentVolume - 25);
                Toast.makeText(getApplicationContext(), "Volume
Decreased", Toast.LENGTH SHORT).show();
                return true;
```

```
case R.id.orientation:
                if(getRequestedOrientation() ==
ActivityInfo.SCREEN ORIENTATION LANDSCAPE)
setRequestedOrientation(ActivityInfo.SCREEN ORIENTATION PORTRAIT);
                else
setRequestedOrientation(ActivityInfo.SCREEN_ORIENTATION_LANDSCAPE);
            default:
                return super.onOptionsItemSelected(item);
        }
    }
    public void setBrightness(int brightness) {
        if(brightness < ∅)</pre>
            brightness = 0;
        else if(brightness > 255)
            brightness = 255;
        currentScreenBrightness = brightness;
        Settings.System.putInt(cResolver,
Settings.System.SCREEN BRIGHTNESS, brightness);
        WindowManager.LayoutParams lp = window.getAttributes();
        lp.screenBrightness = brightness / (float)255;
        window.setAttributes(lp);
    }
    public void setVolume(int volume) {
        if(volume < 0)</pre>
            volume = 0;
        else if(volume > 100)
            volume = 100;
        currentVolume = volume;
        mAudioManager.setStreamVolume(
                AudioManager.STREAM MUSIC,
```

```
(int)
mAudioManager.getStreamMaxVolume(AudioManager.STREAM MUSIC) * volume
/ 100,
                0);
    }
    private void getSPreferences() {
        String[] keys =
((Lab6Application)this.getApplication()).getSPValueKeys();
        mName.setText(mSharedPreferences.getString(keys[∅], ""));
        mEmail.setText(mSharedPreferences.getString(keys[1], ""));
        mContact.setText(mSharedPreferences.getString(keys[2], ""));
    }
    private void clearSharedPreferences() {
        SharedPreferences.Editor editor = mSharedPreferences.edit();
        editor.clear();
        editor.apply();
    }
    private void checkEmptyVal() {
        String name = mName.getText().toString();
        String email = mEmail.getText().toString();
        String contact = mContact.getText().toString();
        if (!(name.equals("") || email.equals("") ||
contact.equals(""))) {
            isStored = Boolean.TRUE;
            Toast.makeText(getApplicationContext(), "Loading values
from Stored Preferences", Toast.LENGTH SHORT).show();
    }
```

(ii) View Activity

```
package com.example.lab6;
```

```
import ...
import org.w3c.dom.Text;
public class ViewActivity extends AppCompatActivity {
    TextView mName, mContact, mEmail;
    Button mBack;
    SharedPreferences mSharedPreferences;
    @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(R.layout.activity view);
        mName = (TextView) findViewById(R.id.name);
        mEmail = (TextView) findViewById(R.id.email);
        mContact = (TextView) findViewById(R.id.phone);
        mBack = (Button) findViewById(R.id.back);
        mSharedPreferences =
getSharedPreferences(((Lab6Application)this.getApplication()).getSPKe
y(), Context.MODE PRIVATE);
        String[] keys =
((Lab6Application)this.getApplication()).getSPValueKeys();
        mName.setText("NAME: " +
mSharedPreferences.getString(keys[0], "No Name"));
        mEmail.setText("E-MAIL: " +
mSharedPreferences.getString(keys[1], "No Email"));
        mContact.setText("CONTACT: " +
mSharedPreferences.getString(keys[2], "No Phone"));
        mBack.setOnClickListener(new View.OnClickListener() {
            @Override
            public void onClick(View view) {
                Intent intent = new Intent(getApplicationContext(),
MainActivity.class);
                startActivity(intent);
```

```
};
};
}
```

(iii) Lab6Application.java

```
package com.example.lab6;
import android.app.Application;

public class Lab6Application extends Application {
    private String SPKey = "secret";
    private String[] SPValueKeys = {"name", "email", "contact"};

    public String getSPKey() {
        return SPKey;
    }

    public String[] getSPValueKeys() {
        return SPValueKeys;
    }
}
```


Video Demo:

https://drive.google.com/file/d/1LSkUCyT0_i-ckBjoNpTsb7UoWSHh3_oH/view?usp=sh aring

APK:

https://drive.google.com/file/d/1Eixcfyuoias9ba4WaOsrLdmCrP00Crzr/view?usp=sharing


Screenshots:



(i) Main Activity

(ii) MainActivity - Input

(iii) ViewActivity



(iv) Main Menu

(v) Controls Menu

Outcomes:

An android application was developed using Menu and SharedPreferences.

Various concepts in Android App Development were explored including:

- Creating and inflating Menus.
- Creating and using SharedPreferences.
- Passing information between Activities using SharedPreferences.
- Declaring and obtaining user-permissions.